WinCT-AD4411

Introduction

Thank you for your interest in our products. Before using this software, be sure to read the following "Software License Agreement" and "Precautions." Also, for the correct usage of this software, do not fail to read the contents of the instruction manual.

Software License Agreement

Use of this software is permitted only to those who agree to the following terms and conditions. Moreover, you shall understand that you agree to be bound by the following terms and conditions at the time you start to use this software.

1. License

A&D Company, Limited (hereinafter called A&D) grants to you the non-exclusive license to use this software free of charge provided you agree to the provisions specified in the terms and conditions on this Software License Agreement.

2. Scope of License

You may make a minimum number of copies of this software solely for backup or achievable purposes. Other than for cases where the terms and conditions on this Software License Agreement apply, the entire software or a part of the software shall not be used, reproduced, revised, adapted, processed or changed, nor may it be leased or transferred to a third party.

3. Copyright

The copyright of this software as well as of manuals, etc. shall belong to A&D and no rights shall occur to you other than the right to use of this software granted by the terms and conditions on this Software License Agreement.

4. Term of the agreement This Software License Agreement shall come into effect at the time you start to use this software.

5. Warranty

A&D shall not undertake, and you hereby expressly waive, any representations or warrantees, including the non-defectiveness of the software.

6. Exemption

A&D shall not be responsible in any way for any loss of expected profit in relation to this software, for loss occurring from special circumstances, (including cases where A&D predicted or could predict the occurrence of damage), as well as for direct or indirect damage to the user by demand for compensation from a third party, irrespective of the reasons.

1. Introduction

WinCT-AD4411 is a Windows application for internal setting value backup and data logging using A&D's AD-4411 series.

2. System requirements

Microsoft® Windows® 10/11

.NET Framework 4.7.2

3. Download for Application

It is a possibility that functional additions and bug fixes are made, so please using the latest version .

The latest version can be downloaded from A&D's home page.

Extract the downloaded zip file to a location of your choice.


4. Connection Methods

According to the manual, connect AD-4411 to the load cell.

Using commercially avilable USB cabble, connect AD-4411 via USB port at the PC.


Power delibery is enable via USB and AD-4411 is ON.

Do not remove the USB cable while the application is runnning. Exit the application before the cable is removed.



5. Starging Application

Double-clic the extracted exe file If the message "Windows protected your PC." appears, run the file from the screen that appears by clicking on More info in the message.




6. Device Connection

Select the port connected to AD-4411 from [COM?] and press [Connect].


During the connection, it will change to [Disconnect].

To exit, press [Disconnect] and [×].



6.1. Change and backup setting value

The [Setting Value] tab provide change and backup setting value.



Open the backup file from the PC and appear it in the left table.

Save the backup file to the PC.


Read out the setting values from AD-4411 and appear them in the left table.

Write the setting value groups selected by check boxes to AD-4411. If it fails because it is out of the setting range, the value area in the left table will turn orange.

Change to the setting value to write.

6.2. Measurement value logging

The [Graph] tab provide measurement value monitoring and logging



Waveforms will be drawn after starting logging.

The current indicated value is displayed.

Set measurement value (Gross) to zero.

Switch the indicated value to mV/V.

Change HPDF setting (cutoff frequency).
A smaller setting value (lower cutoff frequency) will make it more stable, but quicker response.

Start logging. Maximum 65000 points.

Stop logging.

Save logging points to the PC as CSV file.

Select loggin interval from 50m, 1s, 10s or 1min..

The current load cell connection type (CALF17) is displayed.